

Precision regulator

# RP2000 Series

Port size: Rc1/4 Rc3/8

JIS symbol







### **Specifications**

**PresSW** 

Shutoff
SlowStart
FImResistFR
Oil-ProhR
MedPresFR
No Cu/
PTFE FRL
Outdrs FR
F.R.L
(Related)
CompFRL
LgFRL
PrecsR

VacF/R

Clean FR

ElecPneuR

AirBoost

SpdContr Silncr CheckV/ other Jnt/tube

AirUnt

PrecsCompn

ElecPresSw

ContactSW

AirSens

PresSW

AirFloSens

WaterRtSens TotAirSys

(Total Air)
TotAirSys
(Gamma)
RefrDry
DesicDry
HiPolymDry
MainFiltr

Dischrg

etc


Cool

Contr

Descriptions		RP2000-8-08	RP2000-10-08
Working fluid	Vorking fluid Compressed clean air (refer to recommended air circuit on page 453)		mended air circuit on page 453)
Max. working pressure	MPa	1.0 (≈150 psi, 10 bar)	
Min. working pressure	MPa	Set pressure +0.1 (≈′	5 psi, 1 bar) *1
Proof pressure	MPa	1.5 (≈220 psi	15 bar)
Ambient / fluid temperatures	°C	-5 (23°F) to 60 (140°F	) (no freezing) *3
Set pressure	MPa	0.03 (≈4.4 psi, 0.3 bar) to 0	.85 (≈120 psi, 8.5 bar)
Sensitivity		Within 0.2% of full scale	
Repeatability		Within ±0.5% of full scale	
Air consumption	ଥ/min(ANR)	5 or less *2	
Port size		Rc1/4	Rc3/8
Exhaust side port size Rc3/8			
Pressure gauge port size		Rc1/8	
Weight	g	470	

- \*1: Flow rate of the secondary side is to be zero.
- \*2: Conditions where the primary pressure is 0.7 MPa and set pressure is 0.3 MPa. Consumed air is normally released to the atmosphere from the bleed port and EXH port. So, air consumption is the total of consumption volume released from the bleed port and EXH port. Air 1 ℓ/min. (ANR) or less is released from EXH port.
- \*3: The range is -5 to 50°C when a digital pressure sensor is used.

### How to order



- \*1: If an Rc1/2 port size is required, use a pipe adaptor set (model No.: A400-15-W).
- \*2: Attachment is attached.
- \*3: The pipe adaptor set and C type bracket cannot be used together.
- \*4: One R1/8 plug is enclosed with the product.

#### Discrete attachment model No.

Attachment code	Discrete attachment model No.
G49P	G49D-6-P10
В	B220
E	SLW-10A
R2	PPX-R10N-6M

Clean-room specifications

(Catalog No. CB-033SA)


Structure compatible with rechargeable battery manufacturing process

Anti-dust generation structure for use in cleanrooms

Specifications for rechargeable battery (Catalog No. CC-1226A)

Ending RP2000 - ..... -

CKD





F.R.L

F (Filtr)

R (Reg)

L (Lub)

**PresSW** 

Shutoff

SlowStart

FImResistFR

Oil-ProhR

MedPresFR

No Cu/

PTFE FRL

Outdrs FR

F.R.L (Related

CompFRL

**LgFRL** 

**PrecsR** 

VacF/R Clean FR ElecPneuR AirBoost SpdContr Silncr


CheckV/ other

Jnt/tube

TotAirSys

### Internal structure/external dimensions

### Internal structure and parts list



No.	Part name	Material
1	Pressure adjustment knob	Polyacetal resin, stainless steel
2	Cover	Aluminum alloy die-casting
3	Pilot body assembly	Aluminum alloy die-casting, etc.
4	Top body assembly	Aluminum alloy die-casting, etc.
5	Body	Aluminum alloy die-casting
6	Exhaust adaptor	Aluminum alloy die-casting
7	Pilot diaphragm	Hydrogenated nitrile rubber
8	Piston assembly	Aluminum, stainless steel, etc.
9	O-ring	Nitrile rubber
10	Exhaust valve	Copper alloy, hydrogenated nitrile rubber
11	Air supply valve	Copper alloy, hydrogenated nitrile rubber
12	O-ring	Nitrile rubber
13	Bottom cap	Copper alloy

### Operational explanation

Air supplied from IN side is stopped its flow to OUT side by the air supply valve. Some supplied air passes through the orifice to flow into the pilot chamber.

When the **1** pressure adjustment knob is rotated, the pressure adjustment spring is compressed, and the opilot diaphragm and the flapper are pushed down to close the nozzle.

Pressure in the pilot chamber rises, forcing the piston lower to open the @ air supply valve, and to supply air to OUT side. The intake air flows into the feedback chamber, and works on the opilot diaphragm. If the diaphragm is forced upward until the air reaches the pressure of the regulator spring, the opilot diaphragm and flapper are forced upward to open the nozzle, and an extremely small amount of air is released to the atmosphere to reduce pressure in the pilot chamber. At the same time, the OUT side pressure works on the piston to force it upward, the **1** air supply valve is closed and the set pressure is maintained.

When the air is consumed and the pressure drops on the OUT side, the pressure in the feedback chamber also drops. The pilot diaphragm and the flapper are forced lower to close the nozzle. Pressure in the pilot chamber rises, causing the piston to open the 1 air supply valve, compensating for any drop in pressure. If the OUT side pressure increases further than the set pressure, the pressure in the feedback chamber also increases. The opilot diaphragm and the flapper are forced upward to open the nozzle. This allows the pressure in the pilot chamber to decrease, and the piston is forced upward to open the @exhaust valve; the surplus pressure is pumped from EXH port on the OUT side to the atmosphere. This pilot pressure control method using the nozzle and flapper can follow up a minimal pressure change, which enables the high precision pressure control.


### Repair parts list

No.	Part name	Model No.
3	Pilot body assembly	RP2000-PILOT-ASSY
7	Pilot diaphragm	RP2000-PILOT-A551
4	Top body assembly	RP2000-TOP-BODY-ASSY
11	Air supply valve	
12	O-ring	RP2000-BTM-VALVE-ASSY
13	Bottom cap	


Note: Parts No. (8), (9), (10) are contained in the top body assembly (4)

### **Dimensions**





- \*1: Dimensions at the setting pressure of 0 MPa
- \*2: Pressure gauge, digital pressure sensor, C type bracket and silencer are optionally included.
- \*3. Dimensions when the digital pressure sensor is assembled.



## RP2000 Series

### **Dimensions**

F.R.L

F (Filtr)

R (Reg)

L (Lub) PresSW Shutoff

SlowStart

FlmResistFR

Oil-ProhR

MedPresFR

No Cu/ PTFE FRL

Outdrs FR

CompFRL

LgFRL

**PrecsR** 

VacF/R

Clean FR

**ElecPneuR** AirBoost

SpdContr Silncr

CheckV/

Jnt/tube

AirUnt

PrecsCompn

ElecPresSw

ContactSW

AirSens PresSW

Cool

AirFloSens/ Contr

WaterRtSens TotAirSys

(Total Air)

TotAirSys

(Gamma)

RefrDry

DesicDry

HiPolymDry


MainFiltr


Dischrg etc


**Ending** 

other

F.R.L (Related) ● PPX-R10N-6M








Note: Refer to page 1056 for details of digital pressure sensor PPX Series.

### Flow characteristics


● RP2000-10-08




● RP2000-8-08 Primary pressure 0.7 MPa 0.6 Secondary pressure MPa 0.5 0.4 0.3 0.2 0.1 0 Air flow rate m³/min (ANR)

### Relief flow characteristics

● RP2000-10-08






### Pressure characteristics

CKD

● RP2000-\*-08



450

F.R.L F (Filtr)

R (Reg)

L (Lub)

**PresSW** 

Shutoff

SlowStart

FImResistFR

Oil-ProhR

MedPresFR

No Cu/ PTFE FRL

Outdrs FR

F.R.L (Related)

CompFRL

LgFRL

**PrecsR** 

VacF/R

Clean FR **El**ecPneuR

AirBoost

SpdContr

Silncr

CheckV/ other

Jnt/tube

AirUnt

PrecsCompn

ElecPresSw

ContactSW

AirSens

PresSW

AirFloSens/ Contr

WaterRtSens

TotAirSys (Total Air) TotAirSys

(Gamma)

RefrDry

DesicDry HiPolymDry

MainFiltr

Dischrg etc Ending

RP2000-10 cylinder table φ100 1000 900 Recommended range 800 Cylinder speed mm/s 700 φ125 600 φ140 500 φ150 400 φ160 φ180 300 φ200 200 φ230 φ250 100 40


This cylinder table shows the available range according to the air supply and exhaust flow rate of the precision regulator and the required consumption flow rate at the cylinder PUSH/PULL.

Recommended cylinder line (70% of max. flow rate is recommended)


> \* Max. cylinder line (Cylinder directly installed)


### Example of precise pressure control system

Cylinder speed range of RP2000



Effective cross-sectional area mm2





\*1. Dimensions when the digital pressure sensor is assembled.


\* Contact CKD if required for assembly.

Compatible model	Filter	Oil mist filter	Precision regulator	T type bracket set
Product model No.	F3000-W	M3000-W	RP2000	B310-W (2 pcs.)

Max.\*

# RP1000/2000 Series

F.R.L F (Filtr) R (Reg) L (Lub) PresSW Shutoff SlowStart FlmResistFR Oil-ProhR MedPresFR No Cu/ PTFE FRL Outdrs FR F.R.L (Related) CompFRL LgFRL **PrecsR** VacF/R Clean FR ElecPneuR AirBoost SpdContr Silncr CheckV/ other Jnt/tube AirUnt PrecsCompn ElecPresSw ContactSW AirSens PresSW Cool AirFloSens/ Contr WaterRtSens TotAirSys (Total Air) TotAirSys (Gamma) RefrDry DesicDry HiPolymDry MainFiltr Dischrg



etc Ending



Pneumatic components (F.R.L. unit (precision))

### Safety Precautions

Be sure to read this section before use. Refer to Intro Page 63 for precautions for general pneumatic components.


Product-specific cautions: Precision regulator RP1000/2000 Series

### Design/selection

### **A** WARNING

- Use the product in the range of conditions specified for the product.
- Working fluid must be clean air from which solids, water and oil have been sufficiently removed using a dryer, filter and oil mist filter. Never supply oiled air.

As well, when secondary side pressure, etc., is turned OFF, air on the secondary side will pass through the regulator and be discharged from the EXH port. Thus, if secondary piping or load side interior is dirty, malfunction, characteristics deterioration, etc., may occur. Keep the inside of the pipes clean.



### **A**CAUTION

■ Keep the pressure difference between the primary and secondary sides to 0.1 MPa or more. For RP1000-8-04, if the set pressure is 0.3 MPa or over, keep the pressure difference at 0.2 MPa or over. (Precautions for RP1000)

When using under conditions where a small pressure difference exists between the primary and secondary sides, the secondary side pressure may pulsate. In this case, increase the secondary side capacity before use. Or set pressure in the depressurizing direction (high pressure → low pressure). Another method is to set the primary pressure to an extremely high level or to somewhat lower the setting pressure, and restrict the secondary side line. If pulsation continues, contact CKD. When using with a low friction cylinder having constant leakage, the secondary pressure may pulsate depending on the working conditions. In this case, restrict the secondary side line and decrease the pressure setting (high pressure → low pressure) to attenuate pulsation. Consult with CKD if the pulsation still does not cease.

#### (Precautions for RP2000)

If the pressure difference between the primary and secondary sides is large and secondary side piping is large, secondary pressure could pulsate during low flow. In this case, set the primary side to the secondary side pressure +0.1 to 0.2 MPa or restrict the secondary side line. If pulsation continues, contact CKD.


- If the regulator is repeatedly turned ON and OFF with the directional switching valve on the primary side, the set pressure may change greatly. Thus, the directional switching valve should be installed on the secondary side.
- Output pressure exceeding the regulator's set pressure could result in damage or faulty operation of the secondary side devices. Be sure to install a safety device.
- Do not operate the pressure adjustment knob while the primary side is released to the atmosphere, as performance could deteriorate.

### Mounting, installation and adjustment

### **A**CAUTION

- Check IN and OUT indications indicating the air inlet and outlet before connecting. A reverse connection could result in improper operation.
- Do not move or swing the product by the pressure adjustment knob.
- Do not install this product in a location where it may be subject to vibrations or shocks.
- Flush air pipes before connecting the regulator.

- Use sealing tape when piping. Do not use liquid and solid sealant. In addition, ensure that the sealing tape does not enter.
- When using in parallel as shown below, do not use the secondary side as a closed circuit. If a closed circuit is required, be sure to set a check valve on the secondary side.



F.R.L

F (Filtr)

R (Reg)

PresSW

Shutoff

SlowStart

FlmResistFR

Oil-ProhR

MedPresFR

No Cu/ PTFE FRL

Outdrs FR F.R.L

(Related)
CompFRL

LgFRL

PrecsR

VacF/R

Clean FR

ElecPneuR

AirBoost

SpdContr

Silncr CheckV/

other Jnt/tube

AirUnt

PrecsCompn Mech/ ElecPresSw

ContactSW

AirSens PresSW

Cool
AirFloSens/

WaterRtSens

TotAirSys (Total Air) TotAirSys

(Gamma)

DesicDry

HiPolymDry MainFiltr

Dischrg

Ending

CKD

### **RP1000/2000** Series

F.R.L

F (Filtr)
R (Reg)

L (Lub) PresSW

Shutoff

SlowStart FlmResistFR

Oil-ProhR MedPresFR

No Cu/ PTFE FRL Outdrs FR

F.R.L (Related)

LgFRL PrecsR

VacF/R Clean FR

ElecPneuR

AirBoost SpdContr

Silncr CheckV/ other

Jnt/tube

AirUnt PrecsComon

Mech/ ElecPresSw ContactSW

AirSens

PresSW Cool AirFloSens/ Contr

WaterRtSens
TotAirSys
(Total Air)
TotAirSys
(Gamma)

RefrDry

DesicDry HiPolymDry

MainFiltr Dischrg etc

Ending

- Install so that the EXH port is not plugged.
- When installing on a panel, completely loosen and remove the pressure adjustment knob, insert the body into the φ12.5 panel hole, and fix it to the panel with the panel mounting nut. Then, turn the pressure adjustment knob to attach it to the body. Panel mounting nut recommended tightening torque 2 to 3N·m

[Precautions for RP2000]

If the product is installed horizontally with the panel mounting nut, the panel could be damaged by the weight of the product and vibration.

- Use appropriate torque to tighten the pipes when connecting them.
  - The purpose is to prevent air leakage and damage to bolts.
  - First tighten the bolts by hand to ensure that the threads are not damaged, then use a tool.

[Recommended values]

Port thread	Tightening torque N⋅m
Rc1/8	3 to 5
Rc1/4	6 to 8
Rc3/8	13 to 15

### **During use/maintenance**

### **A**CAUTION

### ■ Working air quality

 Use only compressed air. Air containing corrosive gases, fluids or chemicals could result in improper pressure adjustment due to body damage or rubber deterioration.

### ■ Working environment

- Avoid use in the following environments.
- When ambient temperature exceeds the range of -5 to 60°C.
- Where air freezes.
- Places where the unit will be exposed to dripping water and/or cutting oil.
- Highly humid places where dew condenses due to temperature fluctuations.
- Where salt air or splashing seawater contacts the product.
- In atmospheres containing corrosive gases, liquids and chemicals.
- Where the product is exposed to direct sunlight.
- With the precision regulator RP1000, the set pressure fluctuates by approx. 0.12 kPa/°C. The pressure tends to drop when the temperature rises.

#### ■ Precautions for use

- Air constantly leaks from the bleed port. This is necessary for precise pressure control, so do not plug the hole.
- Check primary pressure before setting pressure.
- Pressure higher than the primary pressure cannot be set.
- Turn the pressure adjustment knob clockwise to increase secondary pressure, and counterclockwise to lower pressure.
- Pressure is set in the depressurizing direction (high pressure → low pressure), enabling highly precise setting to be made.
- After adjusting pressure, tighten the lock nut, and then fix the knob.
- The precision regulator RP1000 exhaust valve has a metal seal, so a small amount of secondary side air will leak.

### ■ Maintenance precautions

- Pneumatic components must be disassembled and assembled by qualified personnel.
- Pneumatic Pressure Skill Test Class 2 or higher level is required.
- Read the relevant product instruction manual thoroughly and fully familiarize yourself with the task before disassembling or assembling pneumatic components.
- Personnel must be fully familiar with pneumatic component structure and operational principles and safety requirements.
- Before conducting maintenance, turn the power OFF, stop the supply of compressed air and make sure that there is no residual pressure.

